



Replaces Toro Groundsmaster 4000-D Parts

Rotary Mower - Model 30412
Seat and Controls



All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



Replaces Toro Groundsmaster 4000-D Parts

Rotary Mower - Model 30412
Seat and Controls



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
---------	--------------	--------------	-------------	---------	----------------

Overhaul Kits

1	R120-5179	120-5179	Large Seat Cover - Gray	1	
---	------------------	----------	-------------------------	---	--

Guages amd Controls

57	RTCA18463	108-8024	Seat Switch	1	
58	R99-7435	99-7435	Relay - 70 Amp	1	
59	R80-9330	80-9330	Alarm - Audio	1	
61	R99-7430	99-7430	Relay - 30 Amp	1	
62	R95-8999	95-8999	Switch - Headlight	2	
63	R100-4918	100-4918	Diode	1	
64	R100-8071	100-8071	Lamp - Warning	2	
65	R100-8070	100-8070	Lamp - Warning	1	
66	R151386	106-5269, 121-5159	Ignition Switch Assy	1	
66	R104-2541	104-2541, 88-9830	Switch - Key 6 Lead 5/8 Mt.	1	
66	R343060	218-412, 32-8380, 33-2010, 62-7770, 63-8360, 94-2618	Ignition - Key Set/2	1	
68	R100-8072	100-8072	Switch	1	
69	RX1709565660	98-7611, 99-3463, 99-7611	Kubota Controller	1	

Other Parts Available

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



Replaces Toro Groundsmaster 4000-D Parts

Rotary Mower - Model 30412
Seat and Controls



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
70	R98-1471	93-5212, 94-3500, 98-1471	Steering Wheel Assy - 14 in Incl Cap	1	
71	R98-1468	98-1468	Cap - 14" Steering Wheel	1	
72	R130-7944	104-2213, 114-5074, 130-7944	Valve- Control - Steering	1	
73	R340-2	340-2, 60-1920	Hydraulic Fitting - Striaight	3	
74	R237-22	107-8844, 237-22, 237-78	O-Ring	4	
75	R237-42	237-42, 31-4160	O-Ring	4	
76	R340-77	340-100, 340-77, 95-7889	Hydraulic Fitting	1	
77	R104-3565	104-3565	Pedal Bracket Assy	1	
79	R283-83	283-83, 42194, 93-5343	Pin - Clevis	2	
80	R3290-355	01-159-0050, 3290-355, 58-5370	Pin - Bridge - Snap	2	
81	R3212-4	3212-3, 3212-4, 3212-5	Bolt - Hex HD 7/16-20 x 1 GR5	2	
82	R3253-6	01-166-0710, 23-12-GD, 3253-6, 59-7590	Washer - Lock 7/16 Zinc	2	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



Replaces Toro Groundsmaster 4000-D Parts

Rotary Mower - Model 30412
Seat and Controls



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
83	R150848	100-4928, 106-7848, 110-0413, 110-9720, 95-8910	Belt-Seat	1	
84	R71-8310	71-8310	Spring - Compression	1	
85	R93-5985	93-5985	Spring - Extension	1	
86	R99-7420	100-8493, 99-7420	Plug-Hole	1	
87	R86-5480	86-5480, 95-0986	Nipple - Test	1	
88	R354-79	354-79	Cap-Dust	1	
89	R104-7547	104-7547	Cable - Throttle	1	
90	R256-10	256-10	Bushing - Flanged	2	
91	R302-5	21-6010, 302-11, 302-37, 302-47, 302-5, 302-57, 302-58, 302-6, 31-0300, 32-9660, 60-0800, 62-3880, 92-4181	Fitting - Grease	1	
92	R93-5312	93-5312	Knob	3	
92	R233-48	233-24, 233-48, 30-3370	Knob	3	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



Replaces Toro Groundsmaster 4000-D Parts

*Rotary Mower - Model 30412
Seat and Controls*



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
92	R233-42	1-603175, 120-9752, 233-42, 233-47	Knob	3	
93	R58-4250	58-4250, 99-3497	Catch - Magnetic	1	
94	R104-7545	104-7545	Bracket - Latch	1	
95	R93-5988	93-5204, 93-5988	Hub - Pivot	2	
96	R323-6	01-150-0010, 01-178-0608, 20-47-AD, 20-47-AGD, 3224-2, 323-6, 49-3510, 908034P, 908332	Bolt - Hex HD 3/8-16 x 1 GR5 YZ	2	
97	R84-9100	84-9100	Spring	1	
98	R92-7610	92-7610	Retainer-Spring	1	
99	R453013	01-166-0140, 01-166-0700, 3256-5, 80-4850	Washer - Flat 7/16	1	
100	R2411-36	2411-36, R2411-36	Rod End	3	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



Replaces Toro Groundsmaster 4000-D Parts

Rotary Mower - Model 30412
Seat and Controls



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
101	R323-9	01-150-0190, 01-150-1540, 01-178-0614, 107229, 20-50-AD, 20-50-AGD, 30-9430, 32105-4, 3224-5, 323-9, 513363, 513364, 5377, 908037P	Bolt - Hex HD 3/8-16 x 1-3/4	2	
102	R453011	01-166-0100, 01-166-0120, 01-166-0270, 01-166-0500, 01-166-0600, 01-166-0620, 132-4593, 2356-3, 237-12, 24-10-AD, 24-11-AD, 24-11-BD, 24-12-AD, 24-12-BD, 30-9310, 32-8190, 3256-24, 3256-3, 3256-36, 3256-4, 453011, 47-9950, 48-9220, 513458, 7-0052	Washer - Flat 3/8 SAE Y/Zinc	2	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



Replaces Toro Groundsmaster 4000-D Parts

Rotary Mower - Model 30412
Seat and Controls



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
103	R3296-39	32127-25, 32128-36, 3290-357, 3296-17, 3296-22, 3296-39, 915663P, 99-7443	Locknut - 3/8-16 Nylon	2	
104	R3219-3	01-188-0624, 215-50, 22-13-BJD, 22-13-BJKD, 3219-3	Nut - 3/8-24	1	
105	R93-5368	93-5368	Abrasive - Pedal	1	
106	R93-5347	93-5347	Abrasive - Pedal	1	
107	R3274-105	3274-105	Screw - Button HD Soc Cap	1	
108	R3296-48	119-4039, 32146-7, 3296-34, 3296-48	Locknut - 7/16-14 ESNA	1	
109	R240-5	240-5	Grommet - Rubber	1	
110	R2412-133	01-651-0160, 2412-133	Clamp	2	
111	R32104-116	32104-116	Screw - 12 x 1/2 Sheet Metal Hsw	2	
112	R32141-36	32141-36	Screw Adjustment	1	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



Replaces Toro Groundsmaster 4000-D Parts

Rotary Mower - Model 30412
Seat and Controls



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
113	R443106	01-188-0518, 22-12-AJD, 32111-4, 3217-4, 3217-6, 3218-2, 513295, 513412, 915112P, 915978, 915979	Nut - 5/16-18 Y/Zinc Plated	1	
114	R240-4	240-4	Grommet - Rubber	4	
115	R69-8970	69-8970	Spacer	4	
116	R340-70	340-70	Nut - Lock	4	
117	R33103-016	33103-016, 93-5919	Screw-HHF	4	
118	R322-14	01-150-0830, 01-178-0524, 30-8900, 322-14	Bolt - Hex HD 5/16-18 x 3 GR5	1	
119	R2412-4	2412-4, Oct-70, Oct-80	Clamp - 3/4 in	1	
120	R47-4420	47-4420	Spacer - Adj. Sleeve SS	1	
121	R104-8300	104-8300, 104-8300 , 119-4041	Locknut - 5/16-18 Flanged Y/Zinc	9	
122	R62-6660	62-6660	Spacer	1	
123	R323-8	01-150-0060, 01-178-0612, 20-49-AD, 20-49-AGD, 323-8, 3273-41, 908036P	Bolt - Hex HD 3/8-16 x 1-1/2 GR8	5	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



Replaces Toro Groundsmaster 4000-D Parts

Rotary Mower - Model 30412
Seat and Controls



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
124	R240-11	240-11	Bushing - Rubber - Flanged	10	
125	R340-97	340-97	Hydraulic Fitting - 90 Deg	1	
126	R340-3	340-3	Hydraulic Fitting - Adapter Connector	1	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.