

Replaces Jacobsen LF-570 Parts



Traction Unit Traction Unit





Replaces Jacobsen LF-570 Parts



Traction Unit Traction Unit

Itom	R&R	action Un OEM	It	Oty Order
	Part No.	Part No.	Description	Qty Order Req Quantity
10	RRF10627	2811255, 556418	SilverGuard Oil Filter - Hydraulic	1
Filter	's			
10	R556418	2811255, 556418	Baldwin Oil Filter - Hydraulic	1
11	R557772	557772	Baldwin Hydraulic Filter - Return	1
11	RRF10616	557772	SilverGuard Oil Filter	1
12	RX7000043081	2500809, 555405	Kubota Filter - Fuel	1
12	RRF10516		SilverGuard Fuel Filter	1
13	R5000919	4114746, 5000919	Baldwin Air Filter Element	1
13	RRF10143	4114746, 5000919	SilverGuard Air Filter Element	1
13	RRF10195	4123044, 4133820	SilverGuard Air Filter Element	1
13	R4133820	4123044, 4133820	Baldwin Air Filter Element	1
14	R108-3813	4132821, 4133821	Air Filter - Inner	1
Belts				
20	RX1628297010	5001284	Kubota V-Belt	1
Gaug	es and Controls			
60	RX3756063010	557888	Kubota Starter	1
61	RX1745460010	2811021	Kubota Solenoid - Stop	1
62	RX1606565510	5002743	Kubota Plug - Glow	3

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



Replaces Jacobsen LF-570 Parts



Traction Unit Traction Unit

	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
63	RX1584139010	554018	Kubota Switch - Oil	1	
Othe	r Parts Available				
70	R500596	500596	Tapered Bearing Set - Cup and Cone	2	
71	R254-72	313456	Cup - Bearing	2	
72	R254-94	313089	Tapered Bearing Cone	2	
73	RX1629912360	557878	Kubota Gasket - Exh Man. Na	1	
74	RX1624114520	557873	Kubota Gasket - Head Cover	1	
75	R232-27	232-27, 360111	Stem - Valve w/ Cap	1	
76	R353914	353914	Bolt - Wheel	4	
77	R337317	337317	Hydraulic Fitting - Restricted Flow	1	
77	R353190	353190	Orifice - Hyd Fitting Use w/R337317	1	
78	R361451	361451	Flat Washer 1 x 1-1/2 Hardened Thrust	0	
79	R348856	348856	Clamp - Muffler - 1-1/2	1	